GF1A TRANSFER

SST



00200 00242	Oil Cool Dulle:	
09308-00010	Oil Seal Puller	
09310-35010	Countershaft Bearing Replacer	
09316-12010	Transfer Bearing Replacer	
 09316-60011	Transmission & Transfer Bearing Replacer	
(09316-00011)	Replacer Pipe	
09336-16010	Wrench 55 x 32 mm	
09612-10093	Steering Gear Housing Overhaul Tool Set	
(09612-10061)	Steering Pinion Bearing Replacer	
09636-20010	Upper Ball Joint Dust Cover Replacer	
09930-00010	Drive Shaft Nut Chisel	
09950-00020	Bearing Remover	
		·

	09950-40011	Puller B Set	1
	09930-40011	Fuller D Set	
	(09951-04010)	Hanger 150	
	(00001 01010)	Tidinger 100	
	(09952-04010)	Slide Arm	
	(*****		
	(09953-04020)	Center Bolt 150	
6			
	(09953-04030)	Center Bolt 200	
Film.			
	(09954-04010)	Arm 25	
~~			
	(09955-04061)	Claw No.6	
	(09957-04010)	Attachment	
٨			
	(09958-04011)	Holder	
· -	00070 00711		
	09950-60010	Replacer Set	
Salling Sallin			
9 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8			
	(00054,00000)	Denleser 22	
	(09951-00220)	Replacer 22	
6			
	(09951-00400)	Replacer 40	
_	(09901-00400)	1\6\piac61 40	
(a)			



	(00054 00440)	Darila can AA	
	(09951-00440)	Replacer 44	
(6)			
	(09951-00540)	Replacer 54	
	(00001 00010)		
(0)			
	(09951-00560)	Replacer 56	
	,	· .	
	(09951-00620)	Replacer 62	
	(09952-06010)	Adapter	
	09950-60020	Replacer Set No.2	
/# N 0000			
0000			
	(09951-00750)	Replacer 75	
	(09952-06010)	Adapter	
	00050 70040	Handle Set	
	09950-70010	Handle Set	
	(09951-07100)	Handle 100	
	(33331 07 100)		
رنوا			
	(09951-07150)	Handle 150	
Q.			
	1	1	



RECOMMENDED TOOLS

	09904-00010	Expander Set	
Wall was			
	09905-00012	Snap Ring No.1 Expander	



EQUIPMENT

Dial indicator or dial indicator with magnetic base	
Plastic-faced hammer	
Hammer	
Press	
Torque wrench	



LUBRICANT

Item	Capacity	Classification
Transfer oil	0.5 liters (0.5 US qts, 0.4 Imp. qts)	API GL-5 SAE 75W-90



SSM

Toyota Genuine Seal Packing Black, Three Bond 1207B or Equivalent

